

INSTALLATION CHECKLIST



PLASTICS EXPAND & CONTRACT

Remember that all plastics expand and contract. Poly-Cor HL can expand up to .250" per 98.5" of length.



FLOAT SHEET

Allow the sheet to float on the roof rafters.



REDUCE SCREWS

If screws are used to temporarily hold down the Poly-Cor, drastically reduce the number and install only on one side. Ideally, one screw for each corner of each sheet. (VHB Tape used sparingly can be substituted for screws.)



ELIMINATE ADHESIVE

Eliminate all adhesive. It is not needed and prevents the sheet from moving when temperatures rise.



TRIM SHEET

Trim the sheet .125" off the wall on both sides.

CONTACT US

800.277.7898 Toll Free | 704.597.8200
5010 W. W.T. Harris Blvd | Charlotte, NC 28269
www.piedmontplastics.com